


Summit Revo Mk. II – Intel Edition

BPM-CPURVI-MP

13-15th Gen LGA1700 LGA1851




Notice

- Please read and carefully follow the installation guide in this manual prior to installing. The installation of this block requires some advanced knowledge about your hardware. As such, if you feel uncomfortable with the steps involved in installing this product, please reach out to our customer support for assistance.
- We recommend the use of a leak tester, such as our Bitspower Digital Leak Detector, after completing the assembly of your liquid cooling loop to make sure there are no leaks prior to filling up your loop with coolant.
- **NEVER** use the leak tester when liquid is present in the loop or when the pump is in operation.
- **DO NOT** exceed 0.5 kg/cm² or 7.0 PSI when using the leak tester. Excessive pressure exerted on your loop may result in damage to your liquid cooling components.
- Bitspower is not responsible for any potential damage from the use of a leak tester.
- **NEVER** overtighten or use excessive force during the installation of any components, unless otherwise stated in the instruction. Overtightening will result in damage to your components.
- Bitspower recommends the use of our Bitspower Pellucid Coolant for the best performance of your liquid cooling setup, as well as using Bitspower Dye for your desired color. We advise against the use of pure distilled water as it may lead to the development of scale and algae over time. Avoid using any other non-recommended coolants or liquid. The use of non-recommended coolants or liquid can result in unexpected abnormalities, such as peeling of the coating on your hardware, built-up of deposit or residue that will result in clogs, tube or O-ring degradation and deformation, or improper operation of the coolant pump. Bitspower is not responsible for any issues that may arise from the use of non-recommended coolant.
- **NEVER** mix or introduce components made from different kinds of metal to your liquid cooling loop. Never use Aluminum based liquid cooling components with Bitspower products. Doing this will result in serious damage and leaks with your liquid cooling components and will void your warranty. If you have any doubts or questions about the components you are using, please reach out to our customer support for assistance.
- Bitspower reserves the right to change the design and interpretations of our products without any prior notice. Actual design and color of product may differ from what is shown on our website.


Bitpower Summit Revo Mk. II – Intel Edition

Included Content


- 1** Magnetic top panel 1 PCS



- 2** CPU block(front) 1 PCS



- 3** CPU block(rear) 1 PCS




- 4** Clamping nut 4 PCS




- 5** FlowChannel Fitting 4 PCS



- 6** Retention Bracket 1 PCS



- 7** Insulation pad 1 PCS




- 8** Bolt 4 PCS



- 9** #6-32X10 Screw 4 PCS



- 10** BPA-TP1-2.5G 1 PCS



CPU socket compatibility


Intel LGA 1700 、 1851

Installation Follow the right sequence to install.

 Prior to securing the block to the motherboard, please verify there are no components in the way of the block.
Do not proceed if the block makes contact with any component on the motherboard and contact us for assistance.


step 1

Unscrew the original screws.




step 2

Please remove the original CPU socket retainer and backplate from the motherboard.




step 3

Install the CPU.



step 4


Please pre-assemble the components listed below.






step 5

Assemble the pre-assembled parts from 'Step 4' and the backside block with the motherboard.



step 6

Please pre-assemble the components below.




Please use a 4mm hex wrench (not included).

step 7

Connect the pre-assembled parts from 'Step 6' to the backside block and tighten the tensioner nuts in an X pattern. Finally, cover the magnetic face plate.




Do not overtighten the tensioner nuts. Doing so might result in damage to your components.



step 8

After installation, please tighten the 8 screws on the back.

Please continue to the In/Out Port guidelines in the following page before assembling your loop.




Installation In/Out Port Guidelines

! CAUTION

It is critical that the correct ports on the rear block of the Summit Revo are used as the INLET and OUTLET ports.

Using the incorrect ports will result in poor thermal performance.

Front View



Isometric View

